

Bedside table A188A installation diagram

										
Foot mat	Wheel	Hinge	Waxberry	6CM pointed screw	2.5CM flat-head screw	Minimum self-tapping screw	Plastic parts	Nut	3.5CM flat-head screw	Wrench
A*4	B*4	C*2	D*4	E*12	F*4	G*24	H*2	I*2	J*2	

Caution: When installing, tighten the screws to a moderate degree. Finish the installation process and then fully tighten them!

Installation steps:

Board name and serial number:

The incorrect sequence of the numbers in the installation diagram does not mean that the boards are missing. You just need to install them according to the sequence.



Step 1: Installation of the upper part

