

WASTE & OVERFLOW INSTALLATION GUIDE

Note:

Use Teflon tape on all threaded connections
Measure twice cut once

- A. Seal the overflow drain pipe (7)(8) first, mount it to back side of tub wall. Use the thick washer (10) to prevent any water leakage.
- B. Fasten the grid (11) to inside wall of the tub by lining the hole up with the threads and screw down till tight.
- C. Slide the lock nut (2) and washer (3) onto overflow drain pipe, connect it with drain body (5)
- D. Seal the bottom drain pipe (6)(9) , slide the nut and washer onto it and connect with drain body. Line up the drain piece with the drain hole in the tub. Do the same for bottom tail piece (4).
- E. Loosen screw from side of lift plug (15), install the tub shoe (14) with gasket (13) through the top of the drain hole, screw down until tight.
- F. Reinstall the lift plug, line the screw hole up with the flat side of the stem sticking up from the drain, and tighten the screw in all the way.
- G. After all components are installed place the base flange (1) over the bottom tail pipe before connecting to the waste plumb line. Connect the waste and overflow to plumb lines in the floor. Check for any leakage in the assembly.

TOOLS AND MATERIALS



Adjustable Wrench



Teflon Tape



Screwdriver

