



626-679-3588
service@getprohome.com
www.getprohome.com
162 Atlantic St, Pomona, CA 91768

ASSEMBLY INSTRUCTIONS

BATHROOM VANITY



PRODUCT
INSTRUCTION
VIDEO

MODEL GP-HG6022D-3K





NOTE: Any size of the vanity's installation steps are the same.

INSTALLATION STEPS


1. Prepare the Vanity: Make sure the vanity is in place and securely attached to the wall.

2. Seal the Edges: To prevent water damage and ensure a clean finish, apply a bead of silicone caulk along the edges where the countertop meets the vanity.

(For Example)



3. Attach the Countertop: Secure the solid surface countertop on the vanity.



(For Example)

HOME SERVICES




INSTALLATION VIDEO

Missing Part or Defective?

Please Contact the Customer Service Team

 service@getprohome.com

 626 679 3588