

ASSEMBLY INSTRUCTION

Step 1: First, turn the cabinet upside down onto a carpet or soft cloth with the bottom facing upwards.

Step 2: The base rack is inverted over the cabinet and fixed by aiming at the edge. Ten screws and an electric screwdriver are needed to tighten the screws.

Step 3: After installing the cabinet legs, put on the floor MATS.

Step 4: The partition inside the cabinet only needs to be placed on the nails installed inside.

