

INSTALLATION INSTRUCTIONS

M1808F AND M1809F FLORAL LAMPS

1. Carefully remove lamp from carton and protective plastic wrapping.
2. Firmly holding the base of the flower, pull off the flower shades.
3. Once the flower shade is off, you will see two small pin holes on top of the base.
4. Read the **WARNING** below before installing the quartz halogen bulb.
5. Push the two needles at the base of the halogen bulb into the two pin holes on the base of the flower.
6. Replace the flower shade by firmly holding the base and pushing the flower onto the base, shade will snap on.
7. Follow the same procedure for lighting the bottom floral base.

WARNING!

- Do not touch quartz halogen bulb directly with your fingers. (Oils from fingers will cause early failure to the bulb)
- Use latex gloves or some kind of protection from your fingers and the bulb.
- When replacing bulbs make certain the bulb is fully cooled down before replacing bulbs.



STEP 2



STEP 3



STEP 5



STEP 6



STEP 7