






Floor Heating Cable Cross Section with Prodeso Heat Membrane



*CONSIDERATIONS CONCERNING INSTALLATION OVER EXISTING VINYL FLOORING:

- Vinyl flooring needs to be secured over the entire surface.
- Single vinyl floors ONLY (Multiple layers of vinyl flooring need to be removed)
- If foam or cushioned vinyl has been previously installed, the vinyl flooring needs to be removed entirely and the PRODESO HEAT MEMBRANE needs to be fixed directly to the subfloor.
- Vinyl flooring needs to be clean of debris, dust, oil, grease, and wax substances.
- Outside-perimeter-secured vinyl flooring is NOT acceptable for direct installation of PRODESO HEAT MEMBRANE as it may cause undesired stress to the tile assembly.