

A*96	B*96	C*10	D*2	E*4	F*1	G*44	H*4	I*1	J*2

Remember: tighten the screws by hand initially during installation, and then pull on them. This is completed.

