



1. Install the bracket on the wall with expansion anchor PVC and screw ①.
2. Connect the wire ② to your home line .
3. Install the canopy ④ to the bracket with cap nuts ③.
4. Install the lampshade ⑤ to the fixture with socket ring ⑥.
5. Install the bulb ⑦.

Please read carefully before installation!!!

Note : Please make sure that the electricity is powered off during installation !

Only a professional electrician should install this kind of product !