

Door Assembly Instructions

- 1) Lay cabinet down on its back**
- 2) Take knob out the of the bag and use a screw driver and put the screw through the pre-drill hole and screw the knob on.**
- 3) Lay the door in the space made for the door and line up the holes in the hinges with the pre-drilled holes for the screws. Put the screws in to attach the door.**
- 4) Stand up the piece and it will be complete.**