

# QUICK • TOOL - FREE INSTALLATION



## STEP 1

Prepare the cover and acrylic fixing clips. Two acrylic fixing clips are needed for one board.



## STEP 2

Fold the cover along the bend.



## STEP 3

Fold the cover to a 90 - degree angle.



## STEP 4

Prepare the cover and acrylic fixing clips. Two acrylic fixing clips are needed for one board.



## STEP 5

Install the acrylic clip on the other side at the corner.



## STEP 6

Installation completed.