







- 2.Install the bracket to the ceiling junction box with screw ⑦.
- 3. Connect the wires to your home line with cap connectors $\ \ \otimes$.
- 4.Install the canopy ① to the bracket with cap nuts ②.
- 5.Install the bulb 9.

Please read carefully before installation!!!

Note: Please make sure that the electricity is powered off during installation!

Only a professional electrician should install this kind of product!