



免打孔不伤墙面

专为小空间量身定制 收纳空间更省心

1. Wipe the wall clean with a towel



1.用毛巾将墙面擦拭干净

2. Apply nail-free adhesive evenly



2.均匀涂上免钉胶

3.贴上辅助贴 用力按压

4.48小时后撕掉辅助贴

3. Apply the auxiliary sticker and press firmly

4. Remove the auxiliary sticker after 48 hours