## ASSEMBLY INSTRUCTION

						CVFNR4633			
	PARTS LIST S.NO. DESCRIPTION QTY				S NO	HARDWARE LIST NO. DESCRIPTION QTY			
S.NU.	DESCRIPTION				S.NO.	DESCRIPTION			
A			ТОР	1	1		ALLEN BOLT	8	
					II		WASHER	8	
В	B1		LEGS	1	- 111	$(\mathcal{Q})$	SPRING WASHER	8	
	B2		LEGS	1	IV		ALLEN KEY	1	
STED 1. Dut the Tep on slace surface on unusual days					V		METAL L CLIP	2	
STEP 1. Put the Top on clean surface on upward down, place the Leg as shown as image.					STEP 2. Now place the other Leg as shown as image.				
STEF	<u>2 3.</u> Now tig get tigh	ghten the Bolt with he nten, upright the Tab	elp of hardware. Once Le e.	gs	STEF	P.4. Assembly Complete.			