

DRAPER JAMES

ONE SET INCLUDES					
Window Curtain Rod and Finial Set	Finials	Brackets	Wall Screws	Anchors	Thumb Screws
 35-66 inch 2-Piece Adjustable Rod OR  66-120 inch 3-Piece Adjustable Rod	X 2 	X 2 	X 4 	X 4 	X 2 
	X 2	X 3	X 6	X 6	X 3

INSTRUCTIONS

- Gather the following tools: pencil, measuring tape, screwdriver, and electric drill.
- Position brackets in a desired location above the window by marking wall screw locations with a pencil. Both brackets should be equal distance from the outside of the window and the third bracket in the center.
TIPS: In most spaces, a curtain rod set looks best hung on the wall outside of the window frame. Allow 1 to 3 inches on each side of the window, 2 to 4 inches above the window frame.
- If fixing to drywall, check for buried cables and pipes before using a drill bit. Drill to a depth of 32 mm and insert anchors. If fixing to wooden batten, no anchors are required.
- Mount the brackets with the wall screws provided.
- For 35-66 inch: Connect the two-piece rod together. For 66-120 inch: Connect the three-piece rod together. The rod with the smallest diameter is the middle piece. You can find the middle piece resting inside one of the end pieces.
- Fit one finial to one end of the rod. Slide curtain onto the rod before fitting the other finial.
- Place curtain rod onto the brackets, tighten the thumb screws.