

Installation steps:

Step 1: Drill holes at the desired location.

Step 2: Place the pull handle and flush finger pull to the holes (sandwich the door) and use the L wrench and screws to mount the pull handle and the flush.

