
easy installation
no can neccessary
can be mounted in
new construction or in
remodel application
with closed ceilings
1. Cut a hole
2. Connect wiring
3. Connect light
4. Insert light