

Orifice plates & Installation instructions

For 33 inch Quartz Double Sink (935021)

840.00 mm

790 mm

Cut along the rim curve of the sink

411 mm

460.00 mm

Overall Size

Undermount
Dotted Line Model

Undermount Round Conner Cutting(R12)

HIGOLD® Under-Mount Sink Installation Instruction

Follow these instructions if you are under-mounting your Higold sink into a bench.
NOTE - All Higold undermount sink installations use these instructions. Therefore images may differ from your sink model. Ensure your sink is in perfect condition before installation.

Description	Quantity
A Composite sink	1
B Box of hole plugs, anchor clips and bolts	1

Step 1 - Preparing Benchtop
A template is provided
Cutout template
Counter
Dotted Line
Cut the hole on the benchtop according to cutout template, pay attention to the curve rim and round corner. It is highly recommended to use the real sink measurement to do the cutting.

Step 2 - Prepare mounting clip
Apply adhesive sealant to the clip plate and paste the clip plate underneath the benchtop

Step 3 - Affix Sink Under Bench
Position sink under bench in line with hole
fasten the clip screw