

Assembly Instructions For Poly Dining Chair & Garden Bench

Tools Needed For Assembly

Hammer For Light Tapping
7/16" Wrench
7/16" Socket

Parts List

Seat Assembly (1)
Back Assembly (1)
Right Arm Assembly (1)
Left Arm Assembly (1)

Hardware

1/4" x 2-3/4" Bolts (6)
1/4" x 4-1/2" Bolts (2)
1/4" Washers (8)
1/4" Hex Nuts (8)

Step 1 Lay out and identify all the parts and pieces.

Step 2 Bolt the seat and back assemblies together with the 4-1/2" long bolts. Put a 1/4" washer on the end of the bolt, then put on a 1/4" nut. Tighten with the 7/16" socket.

Step 3 Now take the right arm assembly and find the predrilled holes in the legs. Line them up with the predrilled holes on the side of the seat and insert the 2-3/4" bolts. Now line up the predrilled hole on the back of the arm with the predrilled hole on the back assembly and insert another 2-3/4" bolt. Put a 1/4" washer and a 1/4" nut on each bolt and tighten with the 7/16" wrench or socket. Fasten the other arm assembly in the same manner.