

Components & Installation

2pcs brackets;

1pcs panel;

1pcs guardrail;

2pcs plastic tube locks;

4pcs screws;

1pcs hex wrench



1 M-type guardrail telescopic tube is connected with a plastic tube lock through a knob;



Loosen the plastic tube lock and pull the inner tube of the bracket out according to the above figure;



Pull out the bracket of the inner tube to tighten the plastic tube lock;



Insert the installed M guardrail into the bracket hole as shown above;



Install the matching screws with a hex wrench and tighten;



Install the panel onto the bracket