





KINCAID

—SOLID WOOD SINCE 1946—





www.kincaidfurniture.com
phone :828-728-3261.

607-324/607-325 Rice Carved 5/0 Headboard And Footboard 607-326/607-327 Rice Carved 6/0-6/6 Headboard And Footboard Assembly Instructions

Headboard Hardware List

CODE	DESCRIPTION	QTY
A	 Threaded Bolts "Ó'7B8\$z'6\$	6
B	 Ewtxg'Y cuj gtu'Ó'7B8\$	6
C	 'P w'Ó'7B8\$	6
D	 Spanner Wrench 12mm	1

Footboard Hardware List

CODE	DESCRIPTION	QTY
E	 Threaded Bolts "Ó'7B8\$z'6\$	4
F	 Ewtxg'Y cuj gtu'Ó'7B8\$	4
G	 'P w'Ó'7B8\$	4
H	 Spanner Wrench 12mm	1

IMPORTANT NOTES

- Place all wooden parts on clean and smooth surface such as rug or carpet to prevent the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples and packing straps before you start to assemble.
- Do not tighten all crews and bolts until completely assembled.
- Keep all hardware out of the reach of children

Headboard Assembly Instructions :

- Step a: Attach the treaded bun feet (4) to the square post headboard (5) by screwing into a place tighten by hand only.
- Step 2: Insert the six threaded bolt (A) into the square post headboard (5) and tighten by hand only.
- Step 3: Insert the headboard panel (1) and stretcher (3) onto the threaded bolts protruding from the square post headboard (5). Attach curve washer (B) and nut (C) onto the threads at upper post, middle post and stretcher. Secure by hand at first, tighten evenly using the open wrench (D).
- Step 4: Attach the treaded bolt carved post (6) to the square post headboard (5) by screwing into a place tighten by hand only.
- Step 5: Attach the treaded bolt top finial (7) to the carved post (6) by screwing into a place tighten by hand only.

Footboard Assembly Instructions :

- Step 1: Attach the treaded bun feet (4) to the square post footboard (8) by screwing into a place tighten by hand only.
- Step 2: Insert the four threaded bolt (E) into the square post footboard (8) and tighten by hand only.
- Step 3: Insert the footboard panel (8) onto the threaded bolts protruding from the square post footboard (8). Attach curve washer (F) and nut (G) onto the threads secure by hand at first. Tighten evenly using the open wrench (H).
- Step 4: Attach the treaded bolt carved post (6) to the square post footboard (8) by screwing into a place tighten by hand only.
- Step 5: Attach the treaded bolt top finial (7) to the carved post (6) by screwing into a place tighten by hand only.

MADE IN VIETNAM