

# 3/4" DRAPERY ROD INSTALLATION INSTRUCTIONS - 86-128" ROD SET

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

**SET INCLUDES:**

(A)	(B)	(C)	(D)	(E)	(F)	(G)
X6	X6	X2	X1	X2	X1	X1

**YOU WILL NEED:**

1/4" dia.

**1**

Extends 86-128"

Before installation, measure windows to determine appropriate drapery rod length.

**2**

Use bracket (C) as a guide to mark location for mounting screws (A).

**3**

Drywall

Drill pilot holes into wall with 1/4" drill bit (not included). Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs.

**4**

Repeat steps 2-3 for additional bracket. Use level if necessary.

**5**

Assemble drapery rod (G) by connecting the two larger diameter rods with the threaded connector (F). Then, insert the two smaller diameter rods into each side.

**6**

Center

Connect the rod to brackets (C) using cap screws (E). Determine placement of center bracket (D) and repeat step 2. Remove the rod and repeat step 3 to install.

**7**

Place drapery panels (not included) onto drapery rod and extend to desired length. Drop rod into center bracket (D), and connect rod to brackets (C) using cap screws (E). Tighten set screw on center bracket (D).