



Step :

Prepare 1 pc of the frame.

Revolve it around the rod till the connector get to the junction point.
Key point: start from the middle of the rod and pay attention to the direction (as shown above).

Link the connectors together and push the connectors back into the rod. Now you can move to Step .

Step :

Prepare the other pc of frame. Do the same operation as Step .

Step :

Get the screws from the accesories package.
Use your screw driver the fix the frame on the rod one by one. There are 2pcs of frames to be fixed.

Step :

- Attach mounting plate to electrical junction box, using junction box screws provided in ccesories package.
- Make proper electrical connections (black to hot"L", white to neutral, ground to "GND") with wire nuts provided in accesories package.
- Attach canopy to mounting plate, get the holes to the correct position with the mounting plate.
- Use your screw driver to fix the canopy on the mounting plate with screws.

