

Dome Shelter Set Up Instructions

- Insert the crossbeam assembly through the flag cloth screen insertion sleeve, fasten each corner closed once inserted, and then spread and lay the wall onto a clean flat surface with the Velcro side of the product facing upwards.
- With the flag cloth screen lying flat, place an anchor stake through each of the two innermost lower grommets. Do not yet insert the stakes into the ground.
- Next, affix a support pole into each of the two anchor stakes, and then insert the top end of each support pole into its respective fastening pocket located at the top of the flag cloth screen.
Note: With the above steps completed, it will render only the center panel of the to be “taut”, while the two outer panels will remain “loose”, without using the two additional support poles.
- Stand up the center panel of the product by grasping the two center support poles, and then place it within your desired set up location for the dome shelter.
- Once placed in the desired spot, drive each of the anchor stakes at a 45 degree angle into the ground by using moderate pressure carefully applied downwards from the support poles.
Note: If the ground is too hard, use a rubber mallet to drive the anchor stakes into the ground at a 45 degree angle. This may require removing the poles temporarily from the anchor stakes, and then reinserting them.
- The should now be freestanding at an upright 45 degree angle that faces open towards you.
- Now take one end of the crossbeam corner and carefully bend it downwards and inwards towards the ground, making a bowed arch.
- Using one of the two remaining anchor stakes, fasten this corner to the ground by inserting the anchor stake through the top corner grommet and driving it into the ground, either by hand or with a rubber mallet. Repeat this same step for the opposite corner, fastening it into the ground similarly with the remaining anchor stake.
- Creating the dome shelter may take a little practice, but it is easily achievable and is best set up with the dome opening facing away from heavy gusts of wind. The completed dome shelter shall look as below.



Changing Room Set Up Instructions

- Follow the basic instructions to set up the as a traditional privacy wall.
- Once set up, uproot one corner end of the by removing the anchor stake from the ground, while keeping all remaining stakes rooted.
- Take this corner of the by its outer support pole, and then carefully bend it forward and inwards, as if to simulate creating an arched wall. Reinsert the anchor stake into the ground to secure it.
- **Note:** Due to the bending resistance of the crossbeam at the top, insert the anchor stakes at the bottom at a slight angle, to reinforce the closure of the changing room and to keep its footing in place.
- Repeat these steps for the opposite corner. Once this opposing corner is bended forward and inward, and then secured by an anchor stake into the ground, it should actually touch the other end
- By following these steps, you will create a changing room that is elliptical in shape, as shown below.

