## ASSEMBLY INSTRUCTIONS

## PARTS AND HARDWARE LIST

HEADBOARD | PC
SIDE RAILS WITH CONNECTORS ATTACHED 2 PC
FOOT RAIL | PC
FEET 4 PC
BOLTS 8 PC
LARGE FLAT WASHERS 8 PC
SMALL RING SHIMS 8 PC
WRENCH | PC
CENTER SUPPORT | PC
SLATS | O PC

## INSTALLATION INSTRUCTIONS

STEP 1:

Attach Center Support to Headboard

STEP 2:

A)LINE UP HOLES IN SIDE RAILS TO CONNECTOR ON HEADBOARD.

B)USE BOLTS BY ADDING SHIMS THEN FLAT WASHERS AND TIGHTEN WITH WRENCH

STEP 3:

INSERT CENTER SUPPORT INTO FOOT RAIL

STEP 4:

FOLLOW STEP 3 TO CONNECT THE FOOT RAIL TO SIDE RAILS

STEP 5:

PLACE SLATS INTO GROVES ON SIDE RAILS

CAUTION: DO NOT ATTEMPT TO MOVE THE BED WHEN FULLY ASSEMBLED. THIS COULD RESULT IN DAMAGE TO THE RAILS, HEADBOARD, OR FOOT RAIL.