JRYTIN 47.2” x 23” Wooden Soaking Tub

Installation Instructions
Model: STB06601



- **Quick Start Guide**
  No complicated installation needed.
  1. Place the tub on a flat, stable, level surface.
  2. The drain hose is pre-installed. Pull out the extendable drain hose and insert it into your floor drain.
  3. Press the chrome pop-up drain to open/close.
  4. Fill with clean, warm water to your preferred depth.
- **Installation**
  Tools Required: None
  1. Confirm the tub is stable (no rocking).
  2. Ensure the drain hose connection is secure.
  3. Test the pop-up drain before filling.
- **Natural Wood Hydration (First-Time Use)**
  Minor seepage when new or after long storage is normal for solid wood and not a defect.
  Fill the tub completely and soak 48–72+ hours to help it re-seal.
  If unused for over one month, repeat the process.
  If seepage continues after 72 hours, contact us via your order details page.

The JRYTIN Team