



1-2. Fit the spade handle to the spade pipe, insert and tighten a Ø4x16 screw with a screwdriver.

3-4. Fit the spade to the spade pipe, insert and tighten a Ø4x16 screw with a screwdriver.

5. "Click" the spade assembly to the dump gate.

