

ASSEMBLY INSTRUCTION

STEP1: INSERT (A) INTO
THE HOLE IN THE DECK
STEP2: HOOK SHROUDS
TO THE PLACES (1),
(2), (3), (4), (5),
(6), (7) AND (8)
RESPECTIVELY.

