
ASSEMBLY STEPS:

1. REMOVE ALL BRACKET FROM THE LAMP FIXTURE AND ATTACH THE MOUNTING CROSS BAR [A] ONTO THE WALL BRACKET ON THE WALL AND FASTENING WITH THE MOUNTING SCREWS[B] (2PCS)
2. SLIP THE BACKPLATE [C] ONTO THE MOUNTING CROSS BAR [A].
3. ATTACH THE SOCKET CAP [E] TO THE SOCKET AND FASTEN WITH THE MOUNTING SCREWS [D] (3PCS).
4. PUT THE SHADE[F] ONTO THE SOCKET CAP[E] AND TIGHTEN BY SCREWS [D](3pcs).

CAUTION: PULL ANY EXCESS WIRE THROUGH BOTTOM OF THE LAMP.
TO CLEAN, USE A SOFT CLOTH ONLY.

NOTE: TURN THE POWER OFF (UNPLUG FROM THE WALL OUTLET) BEFORE REPLACING THE BULB. MAKE SURE THE BULB HAS SUFFICIENT TIME TO COOL DOWN. DO NOT SUBJECT THE LAMP TO ANY SHOCK WHILE LIT AS SHATTERING OF LAMP MAY RESULT.

