



- Step 1: Insert masonry plugs into mounting surface A.
- Step 2: Fit mounting bracket onto mounting surface with self-tapping screws A.
- Step 3: Connect main supplier wires to terminal block making sure all the connections are tight B.
- Step 4: Tighten up by provided screws C .
- Step 5: Insert 1xE14 bulb D(not supplied) to the lampholder.