

Orifice plates & Installation instructions

For 33 inch Sink (953454 , 952465)

838.00 mm

791.00 mm

31.14 in

16.14 in

410.00 mm

457.00 mm

Overall Size

Undermount
Dotted Line Model

Undermount Round Conner Cutting(R10)

Installation Instructions Undermount Sinks

NO	Description	Picture	Qty
A	Kitchen Sink		1
B	Accessories Box		1
C	Cut-out Template		1

Step1: Create A Template

Step2: Fix Nuts Holes According To Instructions Below

Hole Size: $\varnothing 11\text{mm}$ (0.43in) with Depth: 1.5mm (0.59in)

Step3: Install The Nuts

Step4: Install The Kitchen Sink

Position right on

45mm (1.77in)

<700mm (27.56in) 700mm-1000mm (27.56in-39.37in) >1000mm (39.37in)