

Step 1



Turn the storage box upside down and install the slide rails

Step 2



Place the storage box in the appropriate position of the cabinet

Step 4



Install 6 bottom screws

Step 3



Complete the installation