

## Easy Installation



Install the handle.



Install the top rail.



Put all the rollers into the rail.



Match the magnet box well and screw in two metal plates.