



4. Install the desk top frame. After the desk top frame is installed, attach double-sided rubber pads. After attaching the double-sided rubber pads to the desk top frame, place the rock plate on it. Ensure that the rock plate is placed flat and in the correct position.

2. Use locking screws to fix the upper frame and the desk top together, ensuring a firm connection and preventing loosening.

5. Place the slab on a double-sided adhesive pad, and then secure it with hardware.

3. Install the black rubber pads. Make sure the rubber pads are installed in the correct position.

1. Install the self-tapping screws for the bottom frame lock. These screws need to be installed on the upper and bottom frame lock adjustment studs of the cabinet to ensure the structural stability of the cabinet.