



ASSEMBLY INSTRUCTION

ITEM NO.: 91103 TV CABINET

NOTE: DON'T TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED !

| PARTS LIST | | |
|------------|-----------------------------------------------------------------------------------|-------|
| A |  | 1 PC |
| B |  | 4 PCS |

STEP#1

