

# Install Tip Guide

- Reversible for a right or left door opening to fit your specific layout
- Up to 1/2-in per side for width adjustment or out-of-plumb
- All measurements should be taken only AFTER walls are finished (tile, backwall, etc.)
- Professional installation is recommended