

Installation process

1



Slide rubber washer & steel washer through all hose then tighten nut

2



Lock the pull down hose with fast connector

3



Attach the weight ball at the labe position

4



Connect cold & hot water hose to angle valve by wrench