

3-Tier Industrial Bookshelf Assembly Guide



This guide provides professional step-by-step assembly instructions for a 3-Tier Industrial Bookshelf with Metal Frame and Backboard.

Parts List

- 2 × Side Metal Frames
- 3 × Wooden Shelves (Top, Middle, Bottom)
- 1 × Backboard Panel
- 4 × Adjustable Feet
- Bolts and Screws Set
- 1 × Allen Key

Assembly Steps

Step 1. Install the adjustable feet into the bottom of both metal side frames.

Step 2. Position the bottom shelf between the side frames and loosely install the bolts.

Step 3. Install the middle shelf and loosely secure all fasteners.

Step 4. Install the top shelf and check alignment.

Step 5. Attach the backboard panel to the rear supports using the supplied screws.

Step 6. Place the bookshelf on a flat surface and verify that it is square.

Step 7. Tighten all bolts from bottom to top.

Step 8. Adjust the feet as needed to eliminate wobbling.

Safety Notes

- Assemble on a soft, clean surface to avoid scratches.
- Do not fully tighten hardware until all parts are installed.
- Do not overload shelves beyond the manufacturer's recommended capacity.
- Use wall anchoring hardware if required for added stability.