



4 - Place the back face (B) onto the frame and align the holes. Screw in place.



5 - Place the top on and screw in place.