

## **Installation Steps**

1. Slot the pipe wall according to the size of the embedded box.
2. Align the embedded box with the hot and cold water inlet pipes and mix water pipe(not included).
3. Water test and leak test.
4. After the test, secure the embedded box with screws.
5. After the ceramic tile is attached, install the panel and rain shower head, and fix the handle with the equipped Allen key.