

## USER GUIDE

# ENTRYWAY CABINET

Natural / Stylish / Unique

## HARDWARE



### ⚠ ATTENTION

- 1 Please always read and follow the assembly, maintenance and operating instruction.
- 2 Do not discard any of the packaging until you have checked that you have all the parts and pack of fittings.
- 3 Keep children away during assembly. This item contains small parts which can be swallowed by children.
- 4 Wipe frames with water gently, do not use bleach, acid, or other solvents.
- 5 Check all hardwares before assembly. Incorrect parts used may lead to damage.



### FINISHED PRODUCT

## ASSEMBLY INSTRUCTIONS

The assembly instructions may vary depending on the number of tiers.



- 1 Position Side Frames (a) (b) on the floor and insert Metal Clips (m) into the pre-drilled holes one by one.

© 2020 - 2023 by Pundarika LLC - MoNiBloom.com



- 2 Install Door Stoppers on each Door Stopper Panel (f) with Short Screws (j).



- 3 Connect both Side Frames with one of the Door Stopper Panel with Door Stopper on top. Secure them with Long Screws (l).



- 4 Insert Back Panel (d) along the groove of the Side Frames.



- 5 Repeat Step 3 & 4 to install the rest Door Stopper Panels and Back Panels.



- 6 Install Top Panel (e) and all Inner Panels (g) with Long Screws (l).



- 7 Install Door Gasket (n), Door Handle (i), and Metal Clips (m) on each Door Panel (c) as picture shown.



- 8 Snap the Door Panels into the Side Frames as picture shown.



- 9 Repeat Step 8 to install the rest of Door Panels.