

LNSTALLATIONINSTRUCTION

x1



x1



x4



x16



x1



NOTE, PUT ALL THE SCREWS INTO THE HOLE SITE, AND THEN TIGHTEN THEM, DO NOT TIGHTEN ONE BY ONE

