## **OFFICE DESK**

# **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### Warning!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.






### ASSEMBLY TIME | 60 MINUTES

#### **PARTS IDENTIFICATION:**



#### **ASSEMBLY INSTRUCTIONS**



Z	HARDWARE IDENTIFICATION						
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	11	HANDLE L=137.5mm		5 PCS
2	WOODEN DOWEL \$\phi 8x30\text{mm}\$		50 PCS	12	HANDLE BOLT (Ø4x28mm BLK)		10 PCS
3	CAM BOLT (Ø7x35.5mm SR)		32 PCS	13	HINGE (Ø35mm SR)		2 PCS
4	CAM LOCK (Ø15x12mm SR)		32 PCS	14	HINGE SCREW (Ø4x15mm SR)	attitu(B)	8 PCS
5	LONG SCREW (Ø4.5x42mm SR)	ATTITUTE ME	8 PCS	15	BOLT (M6x28mm BLK)		8 PCS
6	SCREW (Ø4.3x35mm SR)	**************************************	17 PCS	16	ALLEN WRENCH (4mm SR)		1PC
7	DOOR CATCH		1 PC	17	FLOOR PROTECTOR 38x38mm		4 PCS
8	GLIDES (L = 450mm WHT)	CL CR CR CR CR CR CR CR CR CR CR	1 SET	18	"L" SUPPORT IRON 293mm		2 PCS
9	GLIDES (L = 350mm WHT)	CL CR DL DR	3 SET	19	STICKER Ø20mm		7 PCS
10	GLIDES SCREW (Ø3x10mm SR)		50 PCS				

Z8,Z9,Z11,Z13,Z18 not included in blister packaging.

