

# How to Set up a Southern Motion Sectional

- Arrange the pieces in order, leaving a workable gap between each piece.
- Start with the right arm facing piece and work towards the left side facing making each connection as you go. This will make the process easier.
- Stand in front of the first two sections. Push them together so that the male side (pin) of the piece lines up with the female side (groove) of the other piece. Lift up the male side, move it over so that it's raised above and in line with the female side, and lower the section, locking it in place.
- Connections for each piece will depend upon your sectional configuration. Pieces which are motion will have a connection like (A) pieces which are stationary like (B) however the method for the connections will be the same.
- After the sectional is assembled check the adjustable legs on the wedge and adjust as necessary so that the wedge is level and flat on the floor.



B

A

