



1. Remove the lock nut & teeth lock washer from light fixture ②.

2. Let the wire go through canopy ④, teeth lock washer, ground wire, lock nut, rotate the lock nut to fix the canopy to the fixture.

3. Install the bracket to the junction box with screw ⑥.
 4. Connect the wire to your home line.
 5. Install the fixture to the bracket with cap nuts ⑤.
 6. Install the lampshade ⑧ to the bulbholder with socket ring ③.
 7. Install the bulbs ⑨.

Please read carefully before installation!!!
Note : Please make sure that the electricity is powered off during installation !
Only a professional electrician should install this kind of product !