

Installation Steps Without Tools



Prepare the cover and acrylic fixing clips. Two acrylic fixing clips are needed for one board.

Step 1



Fold the cover along the bend.

Step 2



Fold the cover to a 90 - degree angle.

Step 3



Prepare the cover and acrylic fixing clips. Two acrylic fixing clips are needed for one board.

Step 4



Install the acrylic clip on the other side at the corner.

Step 5



Installation completed.

Step 6