

EASY INSTALLATION



STEP 1: PREPARE THE PIPE



STEP 2: APPLY CEMENT



STEP 3: INSERT THE WYE



STEP 4: ALLOW TO CURE