

Bedding Washing Guide And Maintenance Knowledge

When washing bedding, are we afraid of encountering discoloration, deformation, damage, or other problems that often occur in washing? You offer an effective washing guide and knowledge on the maintenance of home textile products.

Polyester fabric maintenance: polyester fabric can be dry cleaned or washed, but due to the frequent generation of static electricity, it is easy to attract dirt and lint, and not easy to remove. Washing can use any general laundry detergent and household bleach, but white polyester fabric usually can maintain the snow white without bleaching. Polyester fabrics can be safely washed in hotter water. To solve the problem of oily stains and odors, it is recommended to wash frequently and pre-treat problem areas; soak for a while before washing and use a lot of washing machines, rinsing in warm or hot water rather than cold.

Polyester fabric will still have a fairly high color fastness after washing if it is properly dyed, but if there is dye residue in the fabric, it may seep into the washing water and cause other fabrics such as acetate and nylon to stain badly. In order to test the color fastness of polyester fabrics, you can rub some acetone on an inconspicuous part of the fabric, and if there is discoloration, wash it separately at the beginning. Drying polyester clothes, it is recommended to use a clothes dryer, because the blowing air helps prevent wrinkles, but the clothes should be taken out immediately after drying, otherwise it may produce wrinkles; remember to use the automatic cooling function of non-iron clothes drying process.

A fabric softener can be used if necessary to soften or reduce static attraction, but it may not be necessary to use it in every wash. Polyester fabrics are less prone to wrinkling, but if ironing is necessary, it should be done at medium or low temperature because once it gets too hot, the fabric will melt. To avoid pilling, wash and dry polyester clothes with the inside out and minimize the number of machine agitations, and use plenty of water.