

ASSEMBLY INSTRUCTIONS



Fine Furniture for every stage of life




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME PER UNIT	5 MINUTES
------------------------	-----------

Z HARDWARE IDENTIFICATION

Z01 BOLT		Ø8mm * 50mm	12 PCS
Z02 FLAT WASHER		Ø8mm	12 PCS
Z03 SPRING WASHER		Ø8mm	12 PCS
Z04 ALLEN KEY		Ø8mm	1 PC

PARTS IDENTIFICATION

A CABINET








1 PC

B LEG









4 PCS



ATTENTION:Anti tipping safeguard
Please install the Anti tipping hardware
as shown in the drawing this can help to
prevent any tipping issues.

Z99 HARDWARE IDENTIFICATION

NO.	DESCRIPTION	FIGURE	SIZE	QTY
1	PLUG			2PC
2	LARGE SCREW		Ø8×2"	1PC
3	TIGHTWIRE		280mm	1PC
4	SHORT SCREW		Ø8×3/4"	1PC




FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.
This restraint may protection against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may
result in injury and damage.



PRODUT/PART DIMENSIONS:



Note: Dimension tolerance $\pm 5\%$

