

Assembly Instruction

1. Screw the nipple into coupler inside the shade
2. Put the rubber washer and diffuser on the nipple, then secure this by the hex nut
3. Put the cap on the nipple, then secured by finial

