

INSTRUCTIONS FOR CLASSIC HEADBOARD

- 1) Hold up Headboard
- 2) Place Bed Frame in Front of Headboard
- 3) Measure the height of the hole on the Frame to the Headboard
- 4) Drill a hole.
- 5) Place a screw into the hole and through the headboard.
- 6) Tighten with a Bolt
- 7) Do the same for the other side of headboard.

Hardware is not included. Bed Frames vary, so Headboards may not have pre-drilled holes.